


Peripheral connections



Contents

- 1x I-Series 4.0 22" with NFC Touchcomputer
- 1x US power cable
- 1x EU power cable
- 1x AC-DC Power Adapter
- 2x Cable cover security screws
- 2x Tie-Wraps (for cable retention)

Elo Touch Solutions Technical Support
Online self-help: www.elotouch.com/support

America
800-ELO-TOUCH
Tel +1 408 597 8000
EloSales.NA@elotouch.com

Europe(EMEA)
Tel +32 16 930 136
EMEA.Sales@elotouch.com

Asia-Pacific
Tel +86 (21) 3329 1385
EloAsia@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.



Quick Installation Guide

I-Series 4.0 22" with NFC


Revision A
P/N E878794




Go to www.elotouch.com/support to download user manual.





Remove the top side cable cover by lifting upward.



Connect the power cable. The system will power on automatically when plugged in. A tie-wrap (included) can be used to secure the power cable from accidental removal.



Connect an Ethernet cable now (or setup WiFi later). Once all cables are reconnected, reinstall the cable over and secure with included security screw.



After powering on the Elo Backpack, please choose a set up method. To set up your device with EloView, select the "Enroll with Eloview" option. This will take you to a "Connect to Wi-Fi" page to set up your wireless network if no Ethernet is connected.

5 Add device to EloView®

To add your device to your EloView account, go to the EloView web portal at manage.eloview.com. After logging in, go to the 'Devices' page, then click the 'add device' button. Enter the device serial number (see step 3 for location) and a name for the device. Click 'done'.

Your device is now linked to your EloView account and you can assign content to play on the device. If the device is connected via Ethernet the device will automatically load content and settings. Visit www.eloview.com for details.