





1x USB cable

### **Elo Touch Solutions Technical Support**

Online self-help:

www.elotouch.com/support

North America 800-ELO-TOUCH Tel +1 408 597 8000 Fax +1 408 597 8050 EloSales.NA@elotouch.com

Europe Tel +32 (0)16 70 45 00 Fax +32 (0)16 70 45 49 elosales@elotouch.com

**Asia-Pacific** Tel +86 (21) 3329 1385 Fax +86 (21) 3329 1400 EloAsia@elotouch.com

Tel +52 55 2281-6958 EloSales.LATAM@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.







www.elotouch.com

## **Quick Installation Guide**

**EMV** Cradle for MagTek eDynamo

Revision A P/N E754462

© 2018 Elo Touch Solutions, Inc. All rights reserved. ISO 9001

# Installation

Remove the peripheral cover from the touch display and secure bracket with two screws



2 Connect USB cable to touch display



3 Slide eDynamo into bracket and verify each edge engages with bracket



4 Connect USB cable to eDynamo



Slide cover bracket over eDynamo and ensure mounting holes line up



6 Secure cover to bracket using two screws.

