

**Included items:**

- 1 x Dallas Key Module
- 1 x Quick Install Guide
- 2 x Secure Screws
- 2 x Mylar Covers



[www.elotouch.com](http://www.elotouch.com)

## Quick Installation Guide

# X-Series USB Dallas Key TouchComputer

**Elo Touch Solutions Technical Support**

Online self-help:  
<https://www.elotouch.com/support>

**North America**

800-ELO-TOUCH  
Tel +1 408 597 8000  
Fax +1 408 597 8050  
EloSales.NA@elotouch.com

**Asia-Pacific**

Tel +86 (21) 3329 1385  
Fax +86 (21) 3329 1400  
EloAsia@elotouch.com

**Europe**

Tel +32 (0)16 70 45 00  
Fax +32 (0)16 70 45 49  
elosales@elotouch.com

**Latin America**

Tel 786-923-0251  
Fax 305-931-0124  
EloSales.LATAM@elotouch.com

Revision A  
P/N E055598


The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.



Go to <https://www.elotouch.com/support> to download utility/user manual.



Remove cover from computer. Add i-button reader using 2 screws provided. Add 2 mylar covers provided on top of screws.