1x
Audio
Adapter



2x
M3x6
Screw



1x
Braille
Label



Learn more about Elo at **EloTouch.com**

America
Tel +1 408 597 8000
EloSales.NA@elotouch.com

Asia-Pacific
Tel +86 (21) 3329 1385
EloAsia@elotouch.com

Europe(EMEA)
Tel +32 (0)16 930 136
EMEA.Sales@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo, the Elo logo, and Elo Edge Connect are trademarks of Elo Touch Solutions, Inc., registered in many jurisdictions worldwide.

E608806

© 2026 Elo Touch Solution, Inc. All rights reserved.

Quick Installation Guide

Elo Edge Connect™ AUDIO ADAPTER

Revision B
P/N E608806

www.elotouch.com

Go to www.elotouch.com/support to download user manual.



1. Select the location to mount the audio adapter. Mounting options vary by model.



2. Remove the selected peripheral cover from the display head to expose the peripheral bay.



3. Gently press the audio adapter into the peripheral bay making sure the connector is mated.



4. Install the (2) M3x6 pan head screws included with the kit.



5. Remove the liner from the braille label and install in the recess with the correct orientation (braille dots should be towards the bottom of the label).