Contents:

1x PayPoint for Android
2x receipt paper roll
1x US power cord
1x CAT5 Ethernet cable

For software development kit please visit
www.elotouch.com

www.elotouch.com

Quick Installation Guide

Elo PayPoint® for Android

Revision B
P/N E545637

Elo Touch Solutions Technical Support
Online self-help: www.elotouch.com/go/websupport

Technical Support contacts in your region:
www.elotouch.com/go/contactsupport

North America
Elo Touch Solutions
1033 McCarthy Boulevard
Milpitas, CA 95035

800-ELO-TOUCH
Tel +1 408 597 8000
Fax +1 408 597 8050
customerservice@elotouch.com

Europe
Tel +32 (0)16 70 45 00
Fax +32 (0)16 70 45 49
elosales@elotouch.com

Asia-Pacific
Tel +86 (21) 3329 1385
Fax +86 (21) 3329 1400
www.elotouch.com.cn

Latin America
Tel 786-923-0251
Fax 305-931-0124
www.elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively “Elo”) makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.

© 2015 Elo Touch Solutions, Inc. All rights reserved.

Installation

1

Connect power and ethernet cables: Connections are underneath the register near the back.

2



Install receipt paper: Install the paper by pressing the lid release button and lifting up on the printer lid. Note the correct paper orientation from the pictures above.

3

Power on the register: Press the power button. If an ethernet internet connection is available, registration will start automatically when the device powers on.

4



If an internet connection is not found in step 3, hold the power button down for 3 seconds and release. This lets you enter the set-up page to find your WiFi connection. Under the Network Tab, select your WiFi network. Once connected your device should start auto-provisioning itself to your software provider. Once set up is complete, password **1elo** can be used to re-enter your control panel if needed.