Included Items

1 - USB cable with additional power connection

4 - screws, M4x8mm

TE Touch Solutions Technical Support
Online self-help:
www.elotouch.com/go/websupport

Technical Support contacts in your region:
www.elotouch.com/go/contactsupport

North America
TE Touch Solutions
301 Constitution Drive
Menlo Park, CA 94025
www.elotouch.com

Europe
Tel +32 (0)16 35 21 00
Fax +32 (0)16 35 21 01
elosales@elotouch.com

Asia-Pacific
Tel +81 (45) 478-2161
Fax +81 (45) 478-2180
www.tps.co.jp

Latin America
Tel 1-305-428-5210
Fax 1-305-717-4909
www.elotouch.com.ar

Quick Installation Guide
Elo TouchSystems 0700L

Touch and Non-Touch Monitors

Revision B
P/N E979930

TE TOUCH SOLUTIONS
connectivity

www.elotouch.com

Installation

Please go to www.elotouch.com\support to verify you have the latest drivers before installing this device. Turn off your computer before installation.

**1** Remove the cable cover by pressing down on the latch and sliding outward.

2 Install USB cable and route cable through the bottom of the opening as shown.


3 Reinstall the cable cover.

4 (Optional) The monitor can be attached to any standard 75mmx75mm VESA mounting bracket using the 4 - M4x8mm mounting screws included with the monitor.

5 Plug the other end of the cable labeled "DATA cable" to a USB port on the computer.

NOTE: Some computers may require additional power by plugging the "Aux Power Cable" connector into an additional USB port.

DATA Cable

AUX Power Cable

6 Install the DisplayLink and touch drivers on your computer.

Note: This monitor can not function as primary display during boot-up. An additional display must be used to install the DisplayLink driver on the computer.

Elo TouchSystems
TouchTools
DRIVERS AND DOCUMENTATION

CD Contents:
• TE MT Touch Driver 1.4
• TE ST Touch Driver 5.3
• CE Driver Rev 2.0
• User Guides
• Adobe Acrobat Reader

P/N 450201-000 Rev AH

TE TOUCH SOLUTIONS
connectivity